The heating and air conditioning* systems in your Honda provide a comfortable driving environment in all weather conditions.

* Air conditioning is optional on the DX model.

The standard audio system has many features. This section describes those features and how to use them. (If you selected an optional audio system, refer to the operating instructions that came with it.)

On EX and EX-V6 models
The security system helps to discourage vandalism and theft of your Honda.

Heating and Cooling..... 106
What Each Control Does..... 106
How to Use the System..... 109
To Turn Everything Off 112
Climate Control System..... 113
Fully-automatic Operation..... 115
Semi-automatic Operation..... 116
Sunlight Sensor/ Temperature Sensor..... 120
Audio System (DX, LX and LX-V6)..... 121
Operating the Radio..... 122
Adjusting the Sound..... 125
Operating the Cassette Player..... 126
Caring for Cassettes..... 128
Operating the Optional CD Changer..... 129
Protecting Compact Discs..... 131
CD Changer Error Indications..... 132
Audio System (EX and EX-V6)..... 133
Operating the Radio..... 134
Adjusting the Sound..... 138
Audio System Lighting..... 139
Radio Frequencies..... 139
Radio Reception..... 139
Operating the CD Player..... 141
Operating the CD Changer..... 143
Protecting Compact Discs..... 144
CD Player Error Indications..... 145
CD Changer Error Indications..... 146
Operating the Cassette Player..... 147
Tape Search Functions..... 148
Caring for the Cassette Player..... 150
Remote Audio Controls 151
Theft Protection..... 152
Security System..... 153